




Aristo®

***Mig 4004i Pulse,
Mig 4004i Pulse WeldCloud™
380-460 V***



Instruction manual



EU DECLARATION OF CONFORMITY

According to
The Low Voltage Directive 2014/35/EU, entering into force 20 April 2016
The EMC Directive 2014/30/EU, entering into force 20 April 2016
The RoHS Directive 2011/65/EU, entering into force 2 January 2013

Type of equipment
Welding power source

Type designation
Mig 4004i Pulse, from serial number 551-xxx-xxxx (2015 w51)

Brand name or trade mark
ESAB

Manufacturer or his authorised representative established within the EEA

Name, address, and telephone No:
ESAB AB
Lindholmsallén 9, Box 8004, SE-402 77 Göteborg, Sweden
Phone: +46 31 50 90 00, Fax: +46 31 50 92 22

The following harmonised standard in force within the EEA has been used in the design:

EN 60974-1:2012, Arc Welding Equipment – Part 1: Welding Power Sources
EN 60974-10:2014, Arc Welding Equipment – Part 10: Electromagnetic Compatibility (EMC) requirements

Additional Information:

Restrictive use, Class A equipment, intended for use in location other than residential

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within the EEA, that the equipment in question complies with the safety requirements stated above.

Date

Signature

Position

Gothenburg

A handwritten signature in black ink, appearing to read "Stephen Argo". The signature is written in a cursive, flowing style.

Global Director Equipment

2017-09-27

Stephen Argo

CE 2017



EU DECLARATION OF CONFORMITY

According to

The Radio Equipment Directive 2014/53/EU, entering into force 13 June 2016
The RoHS Directive 2011/65/EU, entering into force 2 January 2013

Type of equipment

Welding power source

Type designation

Mig 4004i Pulse WeldCloud, from serial number 608-xxx-xxxx (2016 w08)
Mig 4004i WC Retrofit from serial number 627-xxx-xxxx (2016 w27)

Brand name or trade mark

ESAB

Manufacturer or his authorised representative established within the EEA

Name, address, and telephone No:

ESAB AB
Lindholmsallén 9, Box 8004, SE-402 77 Göteborg, Sweden
Phone: +46 31 50 90 00, Fax: +46 31 50 92 22

The following harmonised standard in force within the EEA has been used in the design:

EN 303 446-2 ElectroMagnetic Compatibility (EMC) standard for combined and/or integrated radio and non-radio equipment; Part 2: Specific conditions for equipment intended to be used in industrial locations.
EN 301 489-1 V2.2.0 Part 1: Common technical requirements
EN 301 489-17 V3.2.0 Part 17: Specific conditions for Broadband Data Transmission Systems
EN 301 489-19 V2.1.0 Part 19: Specific conditions for GPS
EN 301 489-52 V1.1.0 Part 52: Specific conditions for Cellular Communication

Additional Information:

Restrictive use, Class A equipment, intended for use in location other than residential

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within the EEA, that the equipment in question complies with the safety requirements stated above.

Date

Signature

Position

Gothenburg

Global Director Equipment

2016-09-27

Stephen Argo

CE 2017

1	SAFETY	5
1.1	Meaning of symbols	5
1.2	Safety precautions	5
2	INTRODUCTION	7
2.1	Equipment	7
3	TECHNICAL DATA	8
4	INSTALLATION	10
4.1	Location	10
4.2	Lifting instruction	10
4.3	Mains supply	10
5	OPERATION	14
5.1	Connections and control devices	15
5.2	Symbols	16
5.3	Connection of welding and return cable	16
5.4	Turning the power source on/off	16
5.5	Fan control	16
5.6	Thermal protection	16
5.7	VRD (Voltage Reducing Device)	17
5.8	Remote control unit	17
5.9	Arc voltage feedback	17
6	MAINTENANCE	18
6.1	Inspection and cleaning	18
7	TROUBLESHOOTING	19
7.1	Error codes for Mig 4004i WeldCloud™	20
8	ORDERING SPARE PARTS	21
	DIAGRAM	22
	ORDERING NUMBERS	24
	SPARE PARTS LIST	25
	ACCESSORIES	26

1 SAFETY

1.1 Meaning of symbols

As used throughout this manual: Means Attention! Be Alert!

**DANGER!**

Means immediate hazards which, if not avoided, will result in immediate, serious personal injury or loss of life.

**WARNING!**

Means potential hazards which could result in personal injury or loss of life.

**CAUTION!**

Means hazards which could result in minor personal injury.

**WARNING!**

Before use, read and understand the instruction manual and follow all labels, employer's safety practices and Safety Data Sheets (SDSs).



1.2 Safety precautions

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.


1. Anyone who uses the equipment must be familiar with:
 - its operation
 - location of emergency stops
 - its function
 - relevant safety precautions
 - welding and cutting or other applicable operation of the equipment
2. The operator must ensure that:
 - no unauthorised person is stationed within the working area of the equipment when it is started up
 - no-one is unprotected when the arc is struck or work is started with the equipment
3. The workplace must:
 - be suitable for the purpose
 - be free from drafts

4. Personal safety equipment:
 - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves
 - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns
5. General precautions:
 - Make sure the return cable is connected securely
 - Work on high voltage equipment **may only be carried out by a qualified electrician**
 - Appropriate fire extinguishing equipment must be clearly marked and close at hand
 - Lubrication and maintenance must **not** be carried out on the equipment during operation



CAUTION!

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.




NOTE!

Dispose of electronic equipment at the recycling facility!

In observance of European Directive 2012/19/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.



ESAB has an assortment of welding accessories and personal protection equipment for purchase. For ordering information contact your local ESAB dealer or visit us on our website.

2 INTRODUCTION

The power sources **Mig 4004i Pulse** combined with U6, U8₂ or MA25 Pulse and **Mig 4004i Pulse WeldCloud™** combined with U8₂ offer a complete multi-process package supporting MMA, TIG, MIG/MAG and pulse MIG.

The **Mig 4004i Pulse WeldCloud™** is provided with a top mounted control box which enables wireless monitoring.

The power sources are intended for use with the wire feed unit Feed 3004/4804 or YardFeed 2000 and the cooling unit COOL 1. For more information about the feed units and the cooling unit, refer to the Instruction manuals.

ESAB accessories for the product can be found in the "ACCESSORIES" chapter of this manual.

2.1 Equipment

The power source is supplied with:

- 5 m return cable with earth clamp
- instruction manual for the welding power source

For Mig 4004i Pulse WeldCloud™, see the instruction manual WeldCloud™ for WeldCloud™ installation instructions.

3 TECHNICAL DATA

Mig 4004i Pulse / Mig 4004i Pulse WeldCloud™	
Mains voltage	380-460 V, ±10%, 3~ 50/60 Hz
Mains supply S_{scmin}	5.8 MVA
Primary current I_{max}	28 A
No-load power	57 W
Setting range (DC)	
MIG/MAG	16 A / 14.8 V - 400 A / 34 V
MMA	16 A / 20.6 V - 400 A / 36 V
TIG	4 A / 10.2 V - 400 A / 26 V
Permissible load at MIG/MAG	
60 % duty cycle	400 A / 34.0 V
100% duty cycle	300 A / 29.0 V
Permissible load at MMA	
60 % duty cycle	400 A / 36.0 V
100% duty cycle	300 A / 32.0 V
Permissible load at TIG	
60 % duty cycle	400 A / 26.0 V
100% duty cycle	300 A / 22.0 V
Power factor at maximum current	0.95
Efficiency at maximum current	89.5 %
Open circuit voltage	55 V
Operating temperature	-10 to 40 °C (14 to 104 °F)
Transport temperature	-20 to 55 °C (-4 to 131 °F)
Constant sound pressure when idling	<70 dB (A)
Dimensions l×w×h	Mig 4004i Pulse: 613 × 257 × 445 mm (24.0 × 10.1 × 17.5 in.) Mig 4004i Pulse WeldCloud™: 613 × 257 × 517 mm (24.0 × 10.1 × 20.3 in.)
Weight	Mig 4004i Pulse: 45 kg (99.2 lb) Mig 4004i Pulse WeldCloud™: 50 kg (110 lb)
Insulation class	H
Enclosure class	IP23
Application classification	S

Mains supply, $S_{sc min}$

Minimum short circuit power on the network in accordance with IEC 61000-3-12.

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40 °C / 104 °F, or below.

Enclosure class

The **IP** code indicates the enclosure class, i.e. the degree of protection against penetration by solid objects or water.

Equipment marked **IP23** is intended for indoor and outdoor use.

Application class

The symbol **S** indicates that the power source is designed for use in areas with increased electrical hazard.

4 INSTALLATION

The installation must be carried out by a professional.



CAUTION!


This product is intended for industrial use. In a domestic environment this product may cause radio interference. It is the user's responsibility to take adequate precautions.

4.1 Location

Position the welding power source such way that its cooling air inlets and outlets are not obstructed.

For Mig 4004i Pulse WeldCloud™, make sure the antenna on the top box is not covered or blocked.

4.2 Lifting instruction



4.3 Mains supply



NOTE!


Mains supply requirements

This equipment complies with IEC 61000-3-12 provided that the short-circuit power is greater than or equal to S_{scmin} at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power greater than or equal to S_{scmin} . Refer to the technical data in the TECHNICAL DATA chapter.

**NOTE!**

The power source can be powered from a generator. For more information, contact authorised ESAB service personnel.

Check that the unit is connected to the correct mains power supply voltage, and that it is protected by the correct fuse size. A protective earth connection must be made, in accordance with regulations.



A. Rating plate with supply connection data


Recommended fuse sizes and minimum cable areas

	Mig 4004i Pulse/Mig 4004i Pulse WeldCloud™
Mains voltage	380-460 V, +/- 10%, 3~50/60 Hz
Mains cable area	4G4 mm ²
Phase current I_{eff} U_{in} 380 V	20 A
Fuse anti-surge	20 A
Fuse MCB-surge type C	25 A
Phase current I_{eff} U_{in} 400 V	19.2 A
Fuse anti-surge	20 A
Fuse MCB-surge type C	25 A
Phase current I_{eff} U_{in} 415 V	18 A
Fuse anti-surge	20 A
Fuse MCB-surge type C	20 A
Phase current I_{eff} U_{in} 440 V	17.6 A
Fuse anti-surge	20 A
Fuse MCB-surge type C	20 A
Phase current I_{eff} U_{in} 460 V	17 A
Fuse anti-surge	20 A
Fuse MCB-surge type C	20 A



**NOTE!**

The mains cable areas and fuse sizes as shown above are in accordance with Swedish regulations. For other regions, supply cables must be suitable for the application and meet local and national regulations.

Installation of mains cable



If the mains cable needs to be changed, the earth connection to the bottom plate must be made in a correct way. See from the pictures above how to remove the side panel and install the mains cable. No other cable must be attached to this connection point.

Connection instruction 0465 152 883 and 0445 301 880**Connection instruction 0465 152 884**

Power source ordering no.	Default input voltage setting	
0465 152 883	400 V	Delivered with mains cable and plug connected.
0465 152 884	415 V	Delivered with mains cable.
0445 301 880	400 V	Delivered with mains cable and plug connected.

If another mains voltage is required, the cable on the printed circuit board has to be moved to the correct pin (see illustration above), and the mains cable and plug must be changed according to relevant national regulations. This operation has to be made by persons who have appropriate electrical knowledge. The power source must be disconnected from mains while performing this action.



5 OPERATION

General safety regulations for handling the equipment can be found in the "SAFETY" chapter of this manual. Read it through before you start using the equipment!



WARNING!


Secure the equipment - particularly if the ground is uneven or sloping.



NOTE!




To achieve the best possible result at Mig short pulsing, the welding and return cables must not exceed 10 m (33 ft).

5.1 Connections and control devices



- | | |
|--|---|
| <ul style="list-style-type: none"> 1. Negative welding terminal: Return cable 2. Mains power supply switch, 0 / 1 3. Connection for wire feed unit or remote control unit 4. Indicating LED, power supply ON 5. Indicating LED, thermal protection 6. Positive welding terminal: Welding cable 7. Fuse (10 A) for supply voltage (42 V) for feeder unit 8. Mains cable 9. USB memory connection | <ul style="list-style-type: none"> 10. Antenna 11. Indicating LED, white, power supply ON (WeldCloud™) 12. Indicating LED, red, connection status (lit LED = connection error) 13. CAN connection 14. Arc voltage monitoring (+), red banana socket 15. Arc voltage monitoring (-), black banana socket 16. Ethernet connection 17. Robot interface |
|--|---|

5.2 Symbols

	Remote control unit (2)		Overheating (3)
	Power supply ON (4)		

5.3 Connection of welding and return cable

The power source has two outputs, a positive terminal (+) and a negative terminal (-), for connecting welding and return cables.

Connect the return cable to the negative terminal on the power source. Secure the return cable's contact clamp to the work piece and ensure that there is good contact between the work piece and the output for the return cable on the power source.

Recommended maximum current values for connection set cables

I_{max}	Cable area	Cable length
450 A (60% duty cycle)	70 mm ²	2 - 35 m (6.6 ft - 114.8 ft)
350 A (100% duty cycle)		
550 A (60% duty cycle)	95 mm ²	2 - 35 m (6.6 ft - 114.8 ft)
430 A (100% duty cycle)		

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40°C (104°F).

5.4 Turning the power source on/off

Turn the power source on by turning switch (2) to the "1" position. Turn the power source off by turning the switch (2) to the "0" position. Regardless the mains supply is interrupted abnormally or the power source is switched off in the normal manner, the welding data will be stored, so it will be available next time the unit is turned on.

5.5 Fan control

The power source has a time circuit, which keeps the fans running for 6.5 minutes after welding has stopped, after that the unit switches to energy-saving mode. The fans start again when welding begins. The fans run at reduced speed for welding currents up to 150 A, and at full speed for higher currents.



CAUTION!

The fans may start at any time to protect the power source from overheating.

5.6 Thermal protection

The welding power source has thermal protection circuit that operates if the internal temperature becomes too high. When this occurs the welding current is blocked and a fault code is displayed on the control panel. The thermal protection resets automatically when the temperature has fallen within normal operation temperature.

5.7 VRD (Voltage Reducing Device)

The VRD function ensures that the open-circuit voltage does not exceed 35 V when welding is not being carried out. VRD LED is lit when the VRD function is activated. The VRD function must be activated by a qualified service technician, by means of ESAT (ESAB Software Administration Tool, a kit for technical service including a software to manage settings, update of software etc.).

The VRD function is blocked when the system senses that welding has started.

5.8 Remote control unit

For more information about the operation of the remote control unit, see the instruction manual for the control panel.

5.9 Arc voltage feedback

To achieve a good welding result, the arc voltage feedback is a crucial factor. In MIG/MAG welding, the power source is prepared to sense the arc voltage in the wire feeder. Prerequisite for this functionality is that an ESAB wire feeder and an ESAB interconnection cable is used! This method of measuring the arc voltage, compensates for the voltage drop in the welding cable to the wire feeder. With an ESAB torch supporting "TrueArcVoltage", the voltage drop all the way to the contact tip is compensated.



WARNING!

The external arc voltage inputs (the red and black banana sockets) at the back end of the WeldCloud™ top box should **not** be used, unless the equipment has been configured for this setup by authorised ESAB service personnel.



NOTE!

To compensate the voltage drop in the return cable, the power source can be configured (by authorised ESAB service personnel) to use an external arc voltage sense wire from the workpiece.

6 MAINTENANCE

**CAUTION!**

Only persons with the appropriate electrical knowledge (authorised personnel) may remove the cover of the product or carry out service, maintenance or repair work on the welding equipment.

**CAUTION!**

The product is covered by manufacturer's warranty. Any attempt to carry out repair work by non-authorized service centers will invalidate the warranty.

**NOTE!**

Regular maintenance is important for safe and reliable operation.

For information about the cooling unit see the instruction manual for the cooling unit.

6.1 Inspection and cleaning


Check regularly that the power source is free from dirt.

The power source should be regularly blown clean using dry compressed air at reduced pressure. More frequently in dirty environments.

Otherwise the air inlet/outlet may become blocked and cause overheating. To avoid this, the air filter should be regularly cleaned. The filter is built of a large and a small mesh. Make sure that the large mesh is mounted to the upmost part of the power source and the small mesh to the innermost part of the power source.

Replacing and cleaning the dust filter:

1. Release the dust filter according to the figure.
2. Blow the filter clean with compressed air (reduced pressure).
3. Ensure that the filter with the finest mesh is placed towards the grill.
4. Reinstall the filter.



7 TROUBLESHOOTING


Try these recommended checks and inspections before sending for an authorised service technician.

Type of fault	Actions
No arc.	<ul style="list-style-type: none"> • Check that the mains power supply switch is turned on. • Check that the mains, welding current and return cables are correctly connected. • Check that the correct current value is set. • Check the mains power supply fuses.
Welding current is interrupted during welding	<ul style="list-style-type: none"> • Check whether the thermal protection trip has operated (indicated by the orange LED on the front (5)) • Check the main power supply fuses if the LED indicating power supply (4) is not lit. • Check that the return cable is correctly fastened.
The thermal protection trips frequently	<ul style="list-style-type: none"> • Check to see whether the air filters are clogged. • Make sure that you are not exceeding the rated data for the power source (i.e. that the unit is not being overloaded). • Check that the ambient temperature is not above the one for the rated duty cycle 40°C/104°F.
Poor welding performance.	<ul style="list-style-type: none"> • Check that the welding current and return cables are correctly connected. • Check that the correct current value is set. • Check that the correct welding wires are being used. • Check the mains power supply fuses.
Nothing happens when the trigger on the welding torch is pushed.	<ul style="list-style-type: none"> • Check the fuse on the rear part of the power source. • Check if the welding and return cables are damaged. • Check that the wire feeder works correctly. See the wire feeder instruction manual.

7.1 Error codes for Mig 4004i WeldCloud™

The following two status LEDs are located on the front of the Mig 4004i WeldCloud™:

1. White LED to indicate power supply ON
2. Red LED to indicate errors



Errors are indicated by the red LED, using morse code. Present error codes are listed below.

Error code		Description
Morse code ¹⁾	Meaning	
• — —	W	There is no wire connection between the W8 ₂ weld data unit (24AP1) and the Quark 2188/2189 board (25AP1).
• •	I	The Quark 2188/2189 board (25AP1) has got no network connectivity.
LED is steady ON.		Configuration file error (i.e. the configuration file is corrupted)

¹⁾ • symbolises a short LED signal and — symbolises a long LED signal.

For further information about WeldCloud™, see the WeldCloud™ instruction manual (0463 450).

8 ORDERING SPARE PARTS



CAUTION!


Repair and electrical work should be performed by an authorised ESAB service technician. Use only ESAB original spare and wear parts.

Mig 4004i Pulse and Mig 4004i Pulse WeldCloud™ are designed and tested in accordance with the international and European standards **IEC-/EN 60974-1** and **IEC-/EN 60974-10**. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the mentioned standards.


Spare parts and wear parts can be ordered through your nearest ESAB dealer, see the back cover of this document. When ordering, please state product type, serial number, designation and spare part number in accordance with the spare parts list. This facilitates dispatch and ensures correct delivery.

DIAGRAM


Mig 4004i Pulse and Mig 4004i Pulse WeldCloud™



Additional diagram for Mig 4004i Pulse WeldCloud™



ORDERING NUMBERS




Ordering number	Denomination	Type	Note
0465 152 883	Welding power source	Aristo® Mig 4004i Pulse	380-460 V. CE
0465 152 884	Welding power source	Aristo® Mig 4004i Pulse	380-460 V. CE, AU
0445 301 880	Welding power source	Aristo® Mig 4004i Pulse WeldCloud™	380-460 V. CE
0463 396 001	Spare parts list	Mig 4004i Pulse, Mig 4004i Pulse WeldCloud™	







Technical documentation is available on the Internet at: www.esab.com





SPARE PARTS LIST





Item	Ordering no.	Denomination
1	0462 197 001	Dust filter













ACCESSORIES

Trolleys		
0462 151 880	<p>Trolley 11, 4-wheel</p> <p>Not to use with Aristo® Mig 4004i Pulse WeldCloud™.</p>	
0463 125 880	<p>Trolley bracket for Trolley 11</p> <p>Use together with trolley 0462 151 880.</p> <p>Not to use with Aristo® Mig 4004i Pulse WeldCloud™.</p> <p>Option when no cooling unit is assembled.</p>	
0460 564 880 0460 815 880	<p>Trolley 8, 2-wheel</p> <p>Shelf for YardFeed and MobileFeed.</p>	
0460 565 880	<p>Trolley</p> <p>For use together with counter balance device.</p> <p>Not to use with Mig 4004i Pulse WeldCloud™.</p>	
0461 310 880	<p>Trolley adapter kit</p> <p>For fitting of power source Mig 4004i Pulse to trolley 0460 565 880.</p>	
0460 946 880	<p>Stabilizer kit for counter balance (1)</p> <p>Use together with trolley 0460 565 880</p>	







<p>0458 705 880</p> <p>0458 705 882</p>	<p>Counter balance device (includes mast and counter balance) for 300 mm (11 in.) bobbin</p> <p>for 440 mm (17 in.) bobbin</p>	
<p>0463 125 880</p>	<p>Trolley bracket Use together with trolley 0462 151 880. Not to use with Mig 4004i Pulse WeldCloud™. Option when no cooling unit is assembled</p>	
<p>Wire feeders</p>		
<p>0460 526 670</p> <p>0460 526 671</p> <p>0460 526 672</p> <p>0460 526 673</p> <p>0460 526 881</p> <p>0460 526 886</p> <p>0460 526 891</p> <p>0460 526 896</p> <p>0460 526 991</p> <p>0460 526 996</p> <p>0459 906 896</p>	<p>Feed 3004 MA25 Pulse Al</p> <p>Feed 3004w MA25 Pulse Al</p> <p>Feed 3004 MA25 Pulse Steel</p> <p>Feed 3004w MA25 Pulse Steel</p> <p>Feed 3004 U8₂</p> <p>Feed 3004 U6</p> <p>Feed 3004 U8₂, water-cooled</p> <p>Feed 3004 U6, water-cooled</p> <p>Feed 4804 U8₂, water-cooled</p> <p>Feed 4804 U6, water-cooled</p> <p>Yardfeed 2000, water-cooled</p>	
<p>Feeder accessories</p>		
<p>0458 674 880</p>	<p>1 Bobbin cover, plastic</p>	







<p>0459 431 880</p>	<p>1 Bobbin cover, metal</p>	
<p>0455 410 001</p>	<p>1 Adapter for 5 kg (11 lb) bobbin</p>	
<p>0459 233 880</p>	<p>1 Adapter for 440 mm (17 in.) bobbin</p>	
<p>0458 706 880</p>	<p>1 Lifting eye</p>	


<p>F102 440 880 899F50</p>	<p>2 Quick connector Marathon Pac™ 2 Quick connector Marathon Pac™ NA</p>	
<p>0558 002 354</p>	<p>Connector Adapter Marathon Pac™ NA</p>	
<p>0458 707 880</p>	<p>1 Wheel kit for feeder, front wheels turnable</p>	
<p>0457 341 881</p>	<p>1 Strain relief for welding torch</p>	
<p>0459 234 880</p>	<p>Strain relief for interconnection cables</p>	
<p>Cooler</p>		
<p>0462 300 880</p>	<p>Water cooling unit, COOL1</p>	

0456 855 881	Flow guard, COOL1	
Connection set, 70 mm² 10 pole cable plug - 10 pole cable socket		
0459 528 780	1.7 m (5.6 ft)	
0459 528 781	5 m (16.0 ft)	
0459 528 782	10 m (32.8 ft)	
0459 528 783	15 m (49.2 ft)	
0459 528 784	25 m (82.0 ft)	
0459 528 785	35 m (114.8 ft)	
Control panels		
0460 820 880	Aristo®U8₂, complete including holder	
0460 820 881	Aristo®U8₂, plus complete including holder	
0460 877 891	Control cable extension U8₂, 7.5 m (24.6 ft)	
Connection set, 70 mm² 10 pole cable plug - 10 pole cable socket		

ACCESSORIES

0349 312 450	1.7 m (5.6 ft)	
0349 312 451	5 m (16.0 ft)	
0349 312 452	10 m (32.8 ft)	
0349 312 453	15 m (49.2 ft)	
0349 312 454	25 m (82.0 ft)	
0349 312 455	35 m (114.8 ft)	
Connection set water, 70 mm² 10 pole cable plug - 10 pole cable socket		
0459 528 790	1.7 m (5.6 ft)	
0459 528 791	5 m (16.0 ft)	
0459 528 792	10 m (32.8 ft)	
0459 528 793	15 m (49.2 ft)	
0459 528 794	25 m (82.0 ft)	
0459 528 795	35 m (114.8 ft)	
Remote controls		
0459 491 880	Remote control unit MTA1 CAN MIG/MAG: wire feed speed and voltage MMA: current and arc force TIG: current, pulse and background current	
0459 491 883	Remote control unit AT1 CAN MMA and TIG: current	
0459 491 884	Remote control unit AT1 CF CAN MMA and TIG: rough and fine setting of current	
Remote control cable 10 pole - 4 pole		
0459 960 880	5 m (16.0 ft)	
0459 960 881	10 m (32.8 ft)	
0459 960 882	25 m (82.0 ft)	
0459 960 883	0.25 m (114.8 ft)	
Remote adapter kit		

Remote controls		
0459 681 880	For Miggy-/Railtrac	
0459 681 881	For MXH PP and PSF RS3	
Connection kit		
0459 020 883	For MXH™ 300/400w PP connection kit	
For Mig 4004i Pulse WeldCloud™:		
0445 499 880	Trolley, 4-wheel For use with Aristo® Mig 4004i Pulse WeldCloud™.	
0445 499 881	Trolley, 4-wheel Aristo® Mig 4004i Pulse WeldCloud™ with Cool1.	
0462 062 001	USB memory 2 Gb	
0445 501 880	Robot Interface Kit Devicenet WeldCloud™	
0445 501 881	Robot Interface Kit Profibus WeldCloud™	
0445 501 882	Robot Interface Kit CANopen WeldCloud™	
0445 501 883	Robot Interface Kit EtherNet IP WeldCloud™	

For Mig 4004i Pulse:		
0445 302 881	Retrofit Mig 4004i WeldCloud™	

Information on PSF welding torches can be found in separate brochures.

For more information about the accessories contact the nearest ESAB agency.

ESAB subsidiaries and representative offices

Europe

AUSTRIA

ESAB Ges.m.b.H
Vienna-Liesing
Tel: +43 1 888 25 11
Fax: +43 1 888 25 11 85

BELGIUM

S.A. ESAB N.V.
Heist-op-den-Berg
Tel: +32 15 25 79 30
Fax: +32 15 25 79 44

BULGARIA

ESAB Kft Representative Office
Sofia
Tel: +359 2 974 42 88
Fax: +359 2 974 42 88

THE CZECH REPUBLIC

ESAB VAMBERK s.r.o.
Vamberk
Tel: +420 2 819 40 885
Fax: +420 2 819 40 120

DENMARK

Aktieselskabet ESAB
Herlev
Tel: +45 36 30 01 11
Fax: +45 36 30 40 03

FINLAND

ESAB Oy
Helsinki
Tel: +358 9 547 761
Fax: +358 9 547 77 71

GREAT BRITAIN

ESAB Group (UK) Ltd
Waltham Cross
Tel: +44 1992 76 85 15
Fax: +44 1992 71 58 03

ESAB Automation Ltd
Andover

Tel: +44 1264 33 22 33
Fax: +44 1264 33 20 74

FRANCE

ESAB France S.A.
Cergy Pontoise
Tel: +33 1 30 75 55 00
Fax: +33 1 30 75 55 24

GERMANY

ESAB Welding & Cutting GmbH
Langenfeld
Tel: +49 2173 3945-0
Fax: +49 2173 3945-218

HUNGARY

ESAB Kft
Budapest
Tel: +36 1 20 44 182
Fax: +36 1 20 44 186

ITALY

ESAB Saldatura S.p.A.
Bareggio (Mi)
Tel: +39 02 97 96 8.1
Fax: +39 02 97 96 87 01

THE NETHERLANDS

ESAB Nederland B.V.
Amersfoort
Tel: +31 33 422 35 55
Fax: +31 33 422 35 44

NORWAY

AS ESAB
Larvik
Tel: +47 33 12 10 00
Fax: +47 33 11 52 03

POLAND

ESAB Sp.zo.o.
Katowice
Tel: +48 32 351 11 00
Fax: +48 32 351 11 20

PORTUGAL

ESAB Lda
Lisbon
Tel: +351 8 310 960
Fax: +351 1 859 1277

ROMANIA

ESAB Romania Trading SRL
Bucharest
Tel: +40 316 900 600
Fax: +40 316 900 601

RUSSIA

LLC ESAB
Moscow
Tel: +7 (495) 663 20 08
Fax: +7 (495) 663 20 09

SLOVAKIA

ESAB Slovakia s.r.o.
Bratislava
Tel: +421 7 44 88 24 26
Fax: +421 7 44 88 87 41

SPAIN

ESAB Ibérica S.A.
San Fernando de Henares
(MADRID)
Tel: +34 91 878 3600
Fax: +34 91 802 3461

SWEDEN

ESAB Sverige AB
Gothenburg
Tel: +46 31 50 95 00
Fax: +46 31 50 92 22

ESAB International AB

Gothenburg
Tel: +46 31 50 90 00
Fax: +46 31 50 93 60

SWITZERLAND

ESAB Europe GmbH
Baar
Tel: +41 1 741 25 25
Fax: +41 1 740 30 55

UKRAINE

ESAB Ukraine LLC
Kiev
Tel: +38 (044) 501 23 24
Fax: +38 (044) 575 21 88

North and South America

ARGENTINA

CONARCO
Buenos Aires
Tel: +54 11 4 753 4039
Fax: +54 11 4 753 6313

BRAZIL

ESAB S.A.
Contagem-MG
Tel: +55 31 2191 4333
Fax: +55 31 2191 4440

CANADA

ESAB Group Canada Inc.
Mississauga, Ontario
Tel: +1 905 670 0220
Fax: +1 905 670 4879

MEXICO

ESAB Mexico S.A.
Monterrey
Tel: +52 8 350 5959
Fax: +52 8 350 7554

USA

ESAB Welding & Cutting
Products
Florence, SC
Tel: +1 843 669 4411
Fax: +1 843 664 5748

Asia/Pacific

AUSTRALIA

ESAB South Pacific
Archerfield BC QLD 4108
Tel: +61 1300 372 228
Fax: +61 7 3711 2328

CHINA

Shanghai ESAB A/P
Shanghai
Tel: +86 21 2326 3000
Fax: +86 21 6566 6622

INDIA

ESAB India Ltd
Calcutta
Tel: +91 33 478 45 17
Fax: +91 33 468 18 80

INDONESIA

P.T. ESABindo Pratama
Jakarta
Tel: +62 21 460 0188
Fax: +62 21 461 2929

JAPAN

ESAB Japan
Tokyo
Tel: +81 45 670 7073
Fax: +81 45 670 7001

MALAYSIA

ESAB (Malaysia) Snd Bhd
USJ
Tel: +603 8023 7835
Fax: +603 8023 0225

SINGAPORE

ESAB Asia/Pacific Pte Ltd
Singapore
Tel: +65 6861 43 22
Fax: +65 6861 31 95

SOUTH KOREA

ESAB SeAH Corporation
Kyungnam
Tel: +82 55 269 8170
Fax: +82 55 289 8864

UNITED ARAB EMIRATES

ESAB Middle East FZE
Dubai
Tel: +971 4 887 21 11
Fax: +971 4 887 22 63

Africa

EGYPT

ESAB Egypt
Dokki-Cairo
Tel: +20 2 390 96 69
Fax: +20 2 393 32 13

SOUTH AFRICA

ESAB Africa Welding & Cutting
Ltd
Durbanville 7570 - Cape Town
Tel: +27 (0)21 975 8924

Distributors

For addresses and phone numbers to our distributors in other countries, please visit our home page

www.esab.com



www.esab.com

